# CERON GAS FIREPLACE







# **CERONA**

It starts with patented, heat-radiating FireBrick® material. Skillfully molded with seamless cantilevered corners and textured detail, the Cerona takes form. It ends in the only true-arched fireplace of its kind—a modern take on an enduring classic. In 36 and 42-inch sizes.

### **VIVID FIRES**

The flames within the Cerona rise up through an elevated FireBrick burner. It warms. It glows. And adds depth to a luminous ember bed.

### VARIABLE HEAT

Easily adjust the powerful heat output of the Cerona. Up to 30% turndown helps create your ideal warmth. Optional technologies can also distribute heat to other areas of the home.



### **FRONT OPTIONS**

Select a front for a custom look. Available in black, graphite or new bronze.







**CHATEAU** 

**CHATEAU DELUXE** 

**VALENCIA** 

### **FINISHES**







**OPTIONAL REMOTE** 

Set the mood from a distance with an optional remote.

## **CERONA TECHNOLOGIES**



### INTELLIFIRE™ IGNITION SYSTEM

The IntelliFire™ Ignition System (IPI) is an advanced intermittent pilot ignition system. IPI constantly monitors ignition, ensures safe functioning and conserves up to \$10/month in energy costs.



### FIREBRICK® TECHNOLOGY

FireBrick is a patented, energy-saving ceramic material molded into an authentic masonry design. FireBrick produces up to 25% more radiant heat than metal fireboxes—heating rooms faster and using less fuel. This increases efficiency and reduces heating costs.



### DIRECT VENT TECHNOLOGY

Direct Vent fireplaces remove 100% of combustion exhaust and odors outside of the home. These sealed fireplaces provide optimal heat, conserve energy and ensure clean, safe indoor air quality.



### **HEAT ZONE TECHNOLOGY**

Draw heat from the Cerona into another room of the home, up to 20 feet away. When a heat zone kit is run continuously, it will redirect up to 25% of the fireplace's heat to another area, thus reducing wall temperatures above the fireplace. Two heat zones run continuously will redirect up to 50% of the fireplace's heat.

### **SPECIFICATIONS**

MODEL	FRONT WIDTH		BACK WIDTH		HEIGHT		DEPTH		GLASS SIZE	BTU/HR INPUT
	UNIT	FRAMING	UNIT	FRAMING	UNIT	FRAMING	UNIT	FRAMING	OLASS SIZE	Brojriik ii vi O i
CERONA-36	41-1/8 [1046]	42-1/8 [1070]	28-1/2 [724]	42-1/8 [1070]	49-7/8 [1268]	50-1/2 [1283]	21-3/4 [551]	22-1/4 [565]	30-1/4 X 23-1/2 [767 X 595]	25,000-37,500 (NG)
CERONA-42	48-1/8 [1223]	49-1/8 [1248]	35-3/8 [900]	49-1/8 [1248]	54 [1372]	54-1/2 [1384]	21-3/4 [551]	22-1/4 [565]	35-7/8 X 27-3/4 [912 X 704]	32,000-48,000 (NG)

### CERONA-36 TOP VIEW LEFT SIDE VIEW FRONT VIEW RIGHT SIDE VIEW MINIMUM 6" VERTICAL RISE REQUIRED BEFORE 41-1/8 [1046] 90° ELBOW 0 34-1/2 [1268] 23-1/2 [595] [1092] 60-1/2 [1537] 12-1/2 [316] GAS LINE 30-1/4 L 2-1/8 [54] <sup>[</sup> 6-5/8 [169] [767] 33-7/8 7 [178] ELECTRICAL [038] 5-1/2 [130] CERONA-42 FRONT VIEW RIGHT SIDE VIEW **TOP VIEW** LEFT SIDE VIEW MINIMUM 12" VERTICAL RISE REQUIRED BEFORE 48-1/8 [1223] 90° ELBOW 35-3/8 [900]-17-3/4 [450] -47-1/8 [1196] 27-3/4 $\circ$ 38-5/8 [704] [981] [1803] GAS LINE <sup>L</sup>2/1/4 [56] <sup>T</sup>-6-3/4 [170] [912] 9-1/4 [235] 39-1/2 2-1/4 [59] ELECTRICAL 5-3/8 [137]-ACCESS

### **U.S. EFFICIENCIES**

**Steady State** - Since most homeowners use their fireplaces for an extended time while they are in the room, Steady State measures how efficiently your fireplace converts fuel to heat once it is warmed up and running in a "steady state".

FIREPLACE	STEADY STATE
CERONA-36	77.5% (NG), 77.5% (LP)
CERONA-42	78.1% (NG), 78.1% (LP)

**AFUE -** AFUE rating is more typically used with appliances, like your furnace, that continually cycle on and off to maintain a constant temperature.

FIREPLACE	AFUE
CERONA-36	61.4% (NG), 64.8% (LP)
CERONA-42	60.7% (NG), 63.6% (LP)

### **CANADA EFFICIENCIES**

**EnerGuide (CSA P.4.1-15)** - EnerGuide is a rating used in Canada to measure annual fireplace efficiency.

FIREPLACE	ENERGUIDE (CSA P.4.1-15)				
CERONA-36	64.1% (NG), 65.6% (LP)				
CERONA-42	63.0% (NG), 64.1% (LP)				

Dimensions in diagrams are in inches and millimeters. Dimensions in table are in inches. Product information is not complete and is subject to change without notice. Product installation must adhere strictly to instructions shipped with product. We recommend measuring individual units at installation. Assumes the use of 1/2" sheetrock. NOTE: Combustible material should not cover the face. Make sure you do NOT cover the decorative door opening.

Refer to installation manual for detailed specifications on installing this product. Heat & Glo reserves the right to update units periodically. The flame and ember appearance may vary based on the type of fuel burned and the venting configuration used. Actual product appearance, including flame, may differ from product images.

For complete information on this model, please contact us at:



No one builds a better fire

Web: heatnglo.com Phone: (888) 427-3973 E-mail: info@heatnglo.com







### **LIMITED LIFETIME WARRANTY\***

The strongest in the industry, Heat & Glo® provides a limited lifetime warranty on the most important aspects: firebox and heat exchanger.

\*For full warranty details, go to www.heatnglo.com. Fireplace glass and other surfaces get extremely HOT and can cause severe burns if touched. Do not remove the protective safety screen from the front of the glass. Keep a safe distance away. To learn more visit www.heatnglo.com/fireplacesafety

HNG-1065U-0719