


Quick Start for EASY Touch Control


- Power:** Turns stove on/off
- Displays actual room temperature**
- Menu:** Allows you to scroll through three additional menus
- Whisper Mode:** Shows if Whisper is on or off




- Displays Day and Time**
- Message Display Area:** Prompts and messages will appear in top center of screen
- Red Arrow:** Increases desired room temperature
- Setting:** Displays current set temperature
- Blue Arrow:** Decreases desired room temperature



- **Burn Mode:** Choose Room Temperature or Constant Burn
- **Cleaning Prompts:** Check cleaning status
- **Diagnostics:** 6 pages of live performance data
- **Feed Limit:** Adjust the feed rate for proper level of fuel/ash on burn pot
- **Igniter:** Choose between Automatic Ignition or Manual Ignition
- **Room Fan:** Auto Fan for automatic adjustment, Constant Fan to choose the fan speed
- **Schedule:** Program days, times, and temperatures to fit your heating needs
- **Test:** Test electrical components



- **Home Screen Options:** Select extra data to be displayed on home screen
- **Screen Brightness:** Set desired active and inactive brightness
- **Day/Time:** Set the day and time - needed for scheduling feature
- **Fuel Calibration:** Follow the directions on this screen to calibrate the Hours Until Empty accuracy
- **Lock:** Choose to lock your home screen
- **Languages:** Choose your preferred language
- **Units:** Choose Fahrenheit or Celsius, and Pounds or Kilograms
- **Wireless Room Sensor:** Enable the optional wireless room sensor



- **Dealer Information:** Your authorized dealer's contact information
- **Factory Defaults:** Allows you to reset to factory settings
- **USB:** Shows the USB menu
- **Video/Manual:** Scan QR code to view manuals and use and care video

Quick Start for EASY Touch Control, continued



Fill the hopper with pellets




Use the arrows to set room temperature



Touch the power icon

Set Schedule



Step 1: Choose day



Step 2: Set wake time (highlighted by yellow box)



Step 3: Set temperature






Step 4: Choose Whisper Mode on/off



Step 5: Touch Away, Home or Sleep to highlight, then set time and temperature



Copy Schedule

- Copy this day's schedule 
- Choose day for this schedule 
- Paste into each day you want this schedule 

Review Schedule

- Press any block to edit, if needed, or select Back to return to previous menu
- Touch Exit when finished scheduling all seven days

HARMAN®

BUILT TO A STANDARD, NOT A PRICE

harmanstoves.com